

### **PRODUCT REGISTRATION:**

MAKE SURE TO REGISTER YOUR PURCHASE AT http://allensportsusa.com/about/product-registration TO QUALIFY FOR PRODUCT WARRANTY AND TO RECEIVE IMPORTANT PRODUCT NOTIFICATIONS

# MODEL XLT2 BIKE TRAILER

# Owner's Manual should be kept for future reference

- 1. Completely read and understand Owner's Manual before assembling or operating this product.
- 2. This product should be assembled by an adult

# IMPORTANT SAFETY INFORMATION

# MARNING

# Failure to follow these warnings and assembly instructions could result in serious injury or death!

- Immediately discard all plastic bags and plastic wrapping materials!
- Maximum weight capacity for this trailer is two (2) children at 100 pounds, max payload!
- Never use this trailer/stroller if it becomes damaged!
- To avoid serious injury, children should always wear the seat belt and the shoulder straps!
- Do not install a car seat or any other seating device not approved by the manufacturer inside the trailer!
- A reflector that complies with CPSC regulations must be visible on the rear of trailer.
- Never leave children unattended in or around this product!
- Never allow children to assemble, fold, or disassemble this unit!
- Accessories or parcels placed in trailer/stroller may cause it to become unstable!
- Not for use with children under 12 months old! Children must be able to support their own heads!
- Before riding, check that all parts are assembled according to the manufacturer instructions! Also, ensure that the trailer does not interfere with braking, pedaling, or steering of the bicycle!
- Do not allow any of the child's body, clothing, shoe laces, or toys to come into contact with moving parts!
- Make no modifications to the trailer!
- Tires should be inflated to 25-35 PSI for maximum comfort! Check tire pressure before each use!
- Use a foot pump or hand pump to inflate tires! Pressurized air hoses can cause over inflation!
- Periodically re-check all fasteners to make sure they are tight!
- Clean trailer only with soap and water. Do not use solvents!

# SAFETY TOWING TIPS

### TOWING TIPS:

- Make sure your bike brakes work properly! Braking distance is increased when pulling a trailer!
- This trailer is wide! Allow extra clearance near curbs, signs, parked cars, and other obstacles!
- A bicycle with trailer attached requires a wide turning radius! Do not turn sharply!
- Children must wear an approved safety helmet when using this product in trailer mode!
- Never remove protective canopy when pulling children in the trailer!
- Always use the safety flag when pulling this trailer!
- Do not ride over curbs! Avoid bumps and holes! Always signal your turns!
- Use extra caution when turning on uneven pavement, and going downhill!
- Not for use at high speeds! Do not exceed 10 MPH!
- NEVER use this trailer at night!
- Install a rearview mirror on your bike to check on children in trailer!
- Dress children appropriately to prevent them from getting chilled or overheated while riding! Protect against wind-chill in cold temperatures, and provide adequate ventilation and hydration during warmer temperatures.

# VARNING

WARNING



# FULLY ASSEMBLED TRAILER



# PARTS LIST

| QUANTITY | DESCRIPTION   |
|----------|---|
| 1        | Frame w/ Canopy, Sling<br>Seat with 5 point safety<br>harness, tow bar, tow<br>bar coupler and rear<br>wheel bracket attached |
| 2        | 20" Rear wheels   |
| 1        | Safety flag   |

# TRAILER ASSEMBLY & OPERATING INSTRUCTIONS

STEP 1:

Remove the trailer, wheels, hitch arm and walking kit from the box.

- 1. Set the jogger kid aside, as you will install this later.
- 2. Lay the trailer on the ground with the black fabric side down.



IMMEDIATELY DISCARD ALL PLASTIC BAGS AND WHEEL

### **OPEN FRAME**

A. Remove trailer and all components from carton. Unfold trailer by pulling the frame and remove all components from inside (Fig. 2a).

B. Lift both side panels into an upright position (Fig 2b). Lift the crossbar with seatback attached, and slide the connector located on the crossbar into the slot in the locking mechanism on the window panel as show (Fig 2b). Make sure both sides are locked in place. When locking, you will hear an audible "click" to indicate the mechanism is engaged. After assembly, attempt to pull the crossbar out by tugging on the bar - it should not come out

C.To remove the crossbar for folding, press the red release button while pulling the crossbar up and away from the frame (Fig 2c).







# WHEEL INSTALLATION

STEP 1:

Push the button on the outside of the wheel hub.

STEP 2:

Insert the axle through the hanger bracket on the frame as shown (fig 3).

STEP 3: Push all the way in and release the pushbutton. The wheel is automatically locked in place.

STEP 4: Give each wheel a tug to make sure they are secure.



# TOW ARM

STEP 1: Locate the hitch arm, and position on the left side of the trailer, as shown (fig 4a). The hitch arm is held in place by a spring pin and a quick release pin.

STEP 2: Depress the spring pin and insert the hitch arm in the bracket on the frame as shown (fig 4b).

Once the spring pin locks in place in the hole in the bracket, Locate the quick release pin, located on the trailer frame, then Insert the pin through the bracket and into the hole in the tow arm. The pin should go completely through the tow arm and bracket. (fig 4c)

STEP 4: Give the pin a tug to be sure it is secure.







WARNING!

Check this pin periodically during and before each use to be sure it has not become loose. Failure to do so could result in serious injury to you or your child.

# TOP COVER/WINDSCREEN

NOTE:

The clear vinyl windscreen and the protective mesh barrier zip open for loading. In inclement weather, the clear windscreen protects your passengers from the elements. Weather permitting, you can roll up the clear window and affix with Velcro straps provided. The mesh allows ventilation, but prevents debris from entering the trailer.





WARNING!:

Rocks and castoff from the bicycle wheels could injure your child. Never use the trailer without closing the mesh cover. Failure to do so could result in serious injury.

# SAFETY FLAG INSTALLATION

STEP 1:

Assemble the flag and insert the end into the small sleeve on the side of the trailer skin.

WARNING!:

This flag is meant for use only with the trailer. This flag is not a toy. Do not let your child play with this flag at any time. Failure to comply with this warning could result in serious injury of your child.



# **HARNESS**

STEP 1: Place a single child in the center and use the center strap in the middle. For two children use the outer center straps and shoulder straps

STEP 2: Unclip the straps and place your child in the seat. Adjust the upper buckles to fit snugly above your child's shoulders.

STEP 3: The crotch strap buckle should come just below your child's belly button, where a normal belt could lay. Adjust the ladder lock so the buckle is in the correct position

STEP 4: Buckle the two side straps to the crotch strap and adjust snugly so you can fit average size fingers between belt and your child.

STEP 5: The buckle should be centered in your child's abdomen. Hook the shoulder straps to the D-rings on the buckle and adjust the ladder locks so they fit snugly.







# **FOLDING**

STEP 1: To fold your trailer, first, release safety harnesses and allow passengers to exit the trailer

P 2: Make sure to remove any items stored inside the trailer or in the cargo area behind the seat.

STEP 3: Open the rear compartment flap and locate the release latches on the side frame tubes.

STEP 4: To operate the latches, first depress the locking button, and then lift to release the crossbar.

STEP 5: Push crossbar down and away, allowing the two side panels to fold down.

The trailer can be folded with or without the wheels on. If the wheels are removed, they can be stowed inside the trailer when not in use. To remove the wheels, simply push the button in the wheel, and pull the wheel out from the frame.











# STORAGE

The trailer has a rear storage area located behind the seat. This is not intended for items weighing more than 10 lbs. It can be accessed by opening the rear logo flap.



WARNINGI.



# HITCH

### Attaching trailer to bicycle

Your iGO trailer is designed to attach easily to just about any full-size bicycle. The hitch fitting must be attached to the rear axle of the bike. Do not attach to any cycle where it cannot attach to the axle. It is recommended that the bicycle(s) to which the trailer will be attached undergo a safety check by a qualified bicycle mechanic before attaching the trailer to it.

NOTE: This trailer is not designed to be used with electric bikes or motorcycles, or any motorcycle or any motorized vehicle.


STEP 1: Loosen left side rear axle to allow the hitch to attach to frame.


STEP 2: Position hitch over left rear axle of bicycle frame (Fig5a).

STEP 3: Tighten axle nut securely, testing to see the hitch is unable to pull loose (Fig 5b).

STEP 4: Loop Safety Strap around frame and secure to D-ring on hitch arm (Fig 5c).







WARNINGI.

Safety strap must attach to the bike frame when using this product in trailer mode. QR snap pin must be in place and locked before riding. Added weight of it's passengers or cargo, or both will affect the handling characteristics of the bicycle to which it is attached.

### Removal of trailer

STEP 2: Remove QR snap pin from hitch connection

STEP 3: Pull trailer arm away from black hitch

STEP 4: Black Hitch attached to axle can remain with the bicycle for easy reattachment.

# TRAILER MAINTENANCE

Your trailer will give you many years of service with minimal care.

To ensure safe and dependable operation, we recommend the following regular maintenance:

### STFP 1.

Before each ride:

- a. Check all fasteners to make sure they are tight. Tighten or replace if needed
- b. Check to make sure wheels are fully secure in the frame. Wheels must be fully inserted to lock in place, Attempt to pull the wheel out without pushing the release button. Wheel should not move.
- c. Check tires for wear and proper inflation as listed on tire sidewall. Use only hand operated pump to avoid tire damage. Underinflation or overinflation can result in unsafe handling.
- d. Double check hitch attachment, making sure QR pin is locked, and safety strap is in place.
- e. Check harness straps for wear, and make sure buckles lock properly

### STEP 2:

Annual check-up

a. Once a year, or sooner if needed, have the trailer inspected by a qualified bicycle mechanic for signs of wear or needed adjustment.

### STEP 3

As needed

a. Trailer can be clean with mild detergent and water. Do not remove the seat or cover for washing. Do not use harsh chemicals or cleaners, as they may damage the fabrics or the frame materials or surfaces.

# PARKING BREAK

Your trailer is equipped with combination wheel guard/parking brakes for added safety.

When loading or unloading or parking your trailer, engage the parking brakes to prevent the trailer from moving.

### STEP 1:

Figure 6a shows the brake mechanism on the trailer in normal unlocked position. In this case, the locking lever faces forward, parallel to frame. The brake housing also acts as a wheel guard to protect the wheel from direct contact with objects that might stop the wheel.

### STEP 2

Figure 6b shows the parking brake in locked position, appropriate for parking or when loading the trailer.





NOTE

When releasing the brakes, make sure to return the lever to the position parallel to the frame, to fully release the brake.

# WARRANTY

IF YOUR PRODUCT REQUIRES WARRANTY SERVICE, PLEASE DO NOT RETURN IT TO RETAIL STORE.
PLEASE CONTACT:

### **ALLEN SPORTS USA**

(800) 722-5536 ~ CUSTOMERSERVICE@ALLENRACKS.COM

Please note that all returns and exchanges are subject to the return policy of the retailer where the product was originally purchased



R. A. ALLEN CO., INC. 60 THOREAU ST. 161 CONCORD, MA 01742

Product designed in USA, Made in Ningbo, China









10

# MODEL XLT2 JOGGER KIT

# Owner's Manual should be kept for future reference

- 1. Completely read and understand Owner's Manual before assembling or operating this product.
- 2. This product should be assembled by an adult

# IMPORTANT SAFETY INFORMATION

### WARNING #1:

- Failure to follow these warnings and assembly instructions could result in serious injury or death!
- Immediately discard all plastic bags and plastic wrapping materials!
- Maximum weight capacity for this trailer is two (2) children at 100 pounds, max payload!
- Never use this trailer/stroller if it becomes damaged!
- To avoid serious injury, children should always wear the seat belt and the shoulder straps!
- Do not install a car seat or any other seating device not approved by the manufacturer inside the trailer!
- A reflector that complies with CPSC regulations must be visible on the rear of trailer.
- Never leave children unattended in or around this product!
- Never allow children to assemble, fold, or disassemble this unit!
- Accessories or parcels placed in trailer/stroller may cause it to become unstable!
- Not for use with children under 12 months old! Children must be able to support their own heads!
- Before riding, check that all parts are assembled according to the manufacturer instructions! Also, ensure that the trailer does not interfere with braking, pedaling, or steering of the bicycle!
- Do not allow any of the child's body, clothing, shoe laces, or toys to come into contact with moving parts!
- Make no modifications to the trailer!
- Tires should be inflated to 25-35 PSI for maximum comfort! Check tire pressure before each use!
- Use a foot pump or hand pump to inflate tires! Pressurized air hoses can cause over inflation!
- Periodically re-check all fasteners to make sure they are tight!
- Clean trailer only with soap and water. Do not use solvents!

# SAFETY TOWING TIPS

### TOWING TIPS:

- Make sure your bike brakes work properly! Braking distance is increased when pulling a trailer!
- This trailer is wide! Allow extra clearance near curbs, signs, parked cars, and other obstacles!
- A bicycle with trailer attached requires a wide turning radius! Do not turn sharply!
- Children must wear an approved safety helmet when using this product in trailer mode!
- Never remove protective canopy when pulling children in the trailer!
- Always use the safety flag when pulling this trailer!
- Do not ride over curbs! Avoid bumps and holes! Always signal your turns!
- Use extra caution when turning on uneven pavement, and going downhill!
- Not for use at high speeds! Do not exceed 10 MPH!
- NEVER use this trailer at night!
- Install a rearview mirror on your bike to check on children in trailer!
- Dress children appropriately to prevent them from getting chilled or overheated while riding!
   Protect against wind-chill in cold temperatures, and provide adequate ventilation and hydration during warmer temperatures.

# WARNING

WARNING

WARNING



11

# FULLY ASSEMBLED TRAILER + JOGGER



# PARTS LIST



Your XLT2 trailer can accept an optional jogger kit. If not included with your trailer at time of purchase, please contact your retailer for more information on how to purchase this accessory.

### QUANTITY

### **DESCRIPTION**

quick release 16 inch wheel, handlebar, mounting hardware

2 fork tubes

safety wrist strap

# **JOGGER ASSEMBLY**

To install the jogger kit, first remove the hitch arm by releasing opening and releasing the QR pin, then press the spring pin and pull out the arm. Also remove the pin on the opposite side clamp.





STEP 2:

Next, take one arm, ( Right and left arms are not the same, note the screw thread faces up), insert into the aluminum bracket, align with the fixing hole and insert and lock the spring pin.





Make sure spring pin is locked. If not locked, the pin may fall out, releasing the fork. This may cause injury to you or your child.

Tighten the fixing screw into the threaded nut in the bottom of the front frame tube. Perform same action for both fork tubes.



# **INSTALL WHEEL**

STEP 1:

Open the quick release axle skewer to allow the axle to fit inside the plastic fork tips. Align the flats on the axle with the flats on the fork tips, and slide into the slots.T

STEP 2:

Close the QR lever, making sure it is tight. If the wheel Is still loose in the frame, open the release lever, tighten the thumb nut, and close the lever again. Repeat this until there is sufficient resistance to securely lock the wheel.

NOTE:

If the wheel does not track straight, loosen the lever and shift the wheel in the slot to adjust the direction, and retighten.





# **INSTALL HANDLEBAR**

STEP 1

Take the small tubes with hardware, and using bolts and nuts provided, assemble to the holes in the rear of the frame. Using the spanner and hex wrench included, tighten securely as shown.



NOTE

Make sure the long portion of the handlebar fixing tube is up, as shown.

STEP 2:

insert handlebar in the small tubes you have just installed on the frame. Depress the spring pins and allow the handlebar to slide in to the small tubes until they lock in place.





# WARRANTY

IF YOUR PRODUCT REQUIRES WARRANTY SERVICE, PLEASE DO NOT RETURN IT TO RETAIL STORE. PLEASE CONTACT:

### **ALLEN SPORTS USA**

(800) 722-5536 ~ CUSTOMERSERVICE@ALLENRACKS.COM

Please note that all returns and exchanges are subject to the return policy of the retailer where the product was originally purchased



R. A. ALLEN CO., INC. 60 THOREAU ST. 161 CONCORD, MA 01742

Product designed in USA, Made in Ningbo, China

